

OkiLAN 8100e Internal Print Server



Installation Instructions

Print Server Part Number: 70042101

1. *Unpack the print server and remove any shipping materials.*
2. *Turn off the printer, and remove the power cord and interface cable.*


3. Remove the access panel screw.



4. Lift off the access panel.



5. Install the print server:




- a. Align the connector at the bottom of the print server with

the connector on the main board.

- b. Press down until connectors are fully engaged.
- c. Make sure the print server is securely installed.

6. Tighten the 2 screws at each end of the metal plate.



7. Snap off the access panel tab.



8. Replace the access panel:
 - a. Align panel tabs at bottom.
 - b. Swing panel up and in place.
 - c. Tighten the screw.



9. To perform a test, press the test button for 3 seconds. The self diagnostic test and configuration settings are printed.



To install the printer software and view the SoftNIC User's Guide, see the CD-ROM included with your printer.



Okidata America, Inc., Mt. Laurel, NJ 08054
<http://www.okidata.com>

58366101